



BRC543 or BRF343

Brake Lever Install / Fitment Guide



ASV Inventions recommends that this lever be installed by a professional motorcycle technician. ASV Inventions INC. accepts no liability for failures or malfunctions due to improper installation. Install at your own risk.

This lever is designed to fit on the following motorcycles:

KTM	YEAR
790 Duke	19-20
790 Duke	23-24
890 Duke	21-22

ZERO	YEAR
SR/S, SR/F	20-21
SR, SR/S, SR/F	22-24

TRIUMPH	YEAR
Tiger 850 / Sport	22-24
Tiger 900 / Rally / GT / Pro	20-24
Tiger 1200 (HC-1)	22-24

TOOLS:

1. 10mm wrench
2. 5mm hex wrench

1: UNINSTALL BRAKE LEVER

1a) Use a 10mm wrench and a 5mm hex wrench to unscrew the main pivot bolt holding the stock lever in the master cylinder.



1b) Remove the lever. Be careful as the OEM push rod may also fall out of the master cylinder.



2: INSTALL THE ASV LEVER

2a) Place the lever onto the master cylinder and install the main pivot bolt. Do not overtighten as that could cause the lever to stick.



3: SETTING AND TESTING

3a) Turn on your bike's lights and place it in Neutral. Pull the brake lever several times, checking that the brakes are engaging, and that the brake light is activating.

3b) Use the reach adjust dials to set the levers to your desired reach. Adjusting reach will greatly affect brake and clutch engagement. Be sure to test at slow speeds before riding normally.

Congratulations! You have successfully installed the ASV brake lever on your bike! If you have any questions, please contact us.

Need help? Contact ASV!

Our techs are available Monday through Friday, 9am to 5pm PST

Phone: **714.861.1400** Email: info@asvinventions.com

[Register your ASV warranty at asvinventions.com!](https://www.asvinventions.com)